SCHEMATICS

CUSTOMER SERVICE
1-800-446-1071

United States / Gas / Summit (2009-2010) VIEW ALL

MODEL #: 2780301 DESCRIPTION: SUMMIT S-670 LP SS (2009-2010) (USA/CANADA)

Print Schematic



10.08

SEQ	DESCRIPTION	PART#
A	Operating guide, Summit S 670 LP, '09	89207
A	Assembly guide for Summit S 470 LP/NG, '09	90752
C	Literature Kit, Summit S-670 LP, '09	90689

W	Hardware kit, Summit '07	81802
1	Hinge pin/cotter pin kit	70302
2	Weber logo with hardware, '07	70304
2	Lid assembly, Summit 600 '11, SS	70111
3	Thermometer for Genesis/Summit (w/tab)	67731
4	Bezel for Genesis/Summit, '07	67717
5	Hardware pack for handle	65908
5	Handle with bezels/spacers/hardware, Summit 600 series	70369
6	Weber Handle Light, Genesis/Summit '16	65612
7	Rotisserie motor, Type B, '15	65579
8	Plastic latch w/spring	70888
8	Bracket assembly, tuck away rotisserie, '09	70885
9	Warming rack, Summit 600 '07	70190
10	Rod-style grate, SS, 11.8", qty. 1	70372
11	Flavorizer bars, SS, set of 4	70375
12	Single burner tube for main burner, Summit '07, qty 1	70306
13	Small hardware pack	81803
13	Tuck-away table assembly	80553
14	Small hardware pack	81803
14	Tool hook for LHS table, Summit '07	70312
15	LP manifold assembly w/knobs, Summit E/S 600 series/Summit Grill Centers	79175
15	Manifold hardware, Summit '07	88067
16	Wiring harness, Summit 670	70882
16	Light switch, Summit 470/670	40264001
17	Control panel w/artwork, Summit 670	70870
17	Hardware for control panel, Summit '07	88209
18	Hardware for bezels/control panel	88208

18	Small bezel w/fasteners, Summit 470/670	70883
19	Control knob for IR burner/smoker burner, qty 1	70378
20	Lighted control knob assembly, qty. 2	70867
20	Lighted control knob assembly, '12	91538
21	Bezel for main burners with hardware	70318
21	Hardware for bezels/control panel	88208
22	Sear knob assembly	70868
23	Battery pack housing	70880
23	Battery pack head	70879
24	Heat shield/water baffle, Summit 670	70874
24	Hardware for burner tubes, Genesis/Summit '07	88210
25	Aluminum drip pans - package of 10	6417
26	Grease tray, Summit 600 '11, SS	70113
27	Catch pan kit	70379
28	Hardware for tank blocker	88063
28	Tank blocker (catch pan holder), Summit 600 series	70322
29	Lighting instruction label, Summits, US/ES/FC	61373
29	Door magnet	91357
29	LHS door assembly for Summit 600 series, SS - discontinued	70330
29	Hardware for control panel, Genesis '11	62779
29	LHS door assembly, SS, Summit S-600, '10	71103
30	Door handles with hardware	70327
31	RHS door assembly for Summit 600 series, SS	70331
31	Door magnet	91357
31	Hardware for control panel, Genesis '11	62779
31	RHS door assembly, SS, Summit S-600, '10	71104
32	LHS frame assembly	70884

32	Adjustable door hinge	70332
33	Hardware kit for bottom panel	67762
33	Bottom panel for LP Summit 6 burner	70335
34	Rain cover for IR burner, Summit 660 built-in	85650
34	IR Burner wire wrap, Summit '14	43291
34	Hardware for IR cover	70392
35	LP Orifice for IR burner, with nut, 30mb	70384
35	IR burner with bracket	70389
36	Cover box for IR burner	70338
37	Thermocouple nut	20201822
37	Thermocouple with electrode and wire	70390
38	Thermocouple with electrode and wire	70390
39	Gas line for IR burner, 64"	70398
40	Screws for rotisserie forks, qty 4	70380
40	Rotisserie shaft, Summit E/S 600 series, '12	80647
40	Rotisserie hardware for tuckaway rotisserie, w/forks, '10	84116
41	Rod-style grate, SS, 8.1", qty. 1	70373
42	Smoker box assembly	70381
43	Chipper grate, Summit '07 smoker	70187
44	Smoker burner tube, Summit '07	70307
45	Sear burner tube kit, Summit 670	70866
46	LP side burner assembly, Summit '07	70396
46	Hardware for side burner table, Genesis	67765
46	Trivet, SS, Summit	91176
46	Control knob, side burner, grey	30125801
46	Rubber lid bumper for side burner (Qty 1)	81252
46	Side burner ring	91173

46	Ignition assembly for side burner	91174
46	Side burner cap, Summit '03	91175
47	Hardware for cookbox, Summit '10	60600
47	Cookbox, Summit 670 '13	64847
47	Silicone bumpers, quantity 4	70339
47	Flavor bar brackets Summit cookbox 6 burner	64849
48	Hardware for bulkhead, Summit '07	88212
48	LP bulkhead assembly	70344
49	Corrugated gas line, main, Summit 600 series	70309
50	Hardware for side burner lid, Summit '07	67719
50	Side burner lid with hardware	67720
51	Side burner table and lid assembly	70348
52	QCC1 hose and regulator, 30"	65909
52	Hose clip w/tag, Genesis/Summit '07	81611
53	Small hardware pack	81803
53	RHS tool holder with hardware	70349
54	Transfer line for side burner	70371
55	Frame connector and hardware, Summit 6 burner	70351
55	Hardware for frame/rear panel, Genesis '11	62776
56	Rear panel, LP Summit 600 series	70354
57	Adjustable door hinge	70332
57	RHS frame assembly, Summit '07	70791
58	Tank scale, Genesis '07	88214
59	Glide buttons and hardware	88065
60	Match holder	81544
61	Fixed caster with insert (qty 1)	70359
62	Locking caster with insert (qty 1)	70360

410	Lighting instruction label, Summits, US/ES/FC	61373
470	Hardware for side burner lid, Summit '07	67719
470	Hardware kit for bottom panel	67762
470	Hardware for bulkhead, Summit '07	88212
470	Hardware for tank blocker	88063
470	Glide buttons and hardware	88065
470	Manifold hardware, Summit '07	88067
470	Hardware for bezels/control panel	88208
470	Hardware for control panel, Summit '07	88209
470	Hardware for burner tubes, Genesis/Summit '07	88210
470	Hardware for side burner table, Genesis	67765
470	Hinge pin/cotter pin kit	70302
470	Silicone bumpers, quantity 4	70339
470	Hardware for IR cover	70392
470	Hardware kit, Summit '07	81802
470	Small hardware pack	81803
470	Hardware for frame/rear panel, Genesis '11	62776
470	Hardware for cookbox, Summit '10	60600
470	Thermocouple nut	20201822
470	Rotisserie hardware for tuckaway rotisserie, w/forks, '10	84116
480	Ignition assembly for side burner	91174
480	Catch pan kit	70379
510	Griddle for Summit E/S 420/670	7404
510	Cover, Summit 600 series	7109
510	Aluminum drip pans - package of 10	6417
510	Weber Style Premium Cast-Iron Plancha Summit 400/600 Series	7577
510	Weber Elevations Tiered Cooking System Grill Rack and Skewer Set	7615

510	Weber Elevations Tiered Cooking System Basket with Frame	7616
510	Weber Original Gourmet BBQ System Poultry Roaster	8838
510	Weber Original Gourmet BBQ System Korean Barbecue - discontinued	8840
510	Weber Original Gourmet BBQ System Ebelskiver	8841
510	QCC1 hose and regulator, 30"	7627
510	Weber Elevations Tiered Cooking System Expansion Rack	7617
510	Weber Elevations Tiered Cooking System 4-Piece Skewer Set	7618
510	Weber Original Gourmet BBQ System Griddle	7421
510	Weber Original Gourmet BBQ System Wok	7422
510	Gourmet BBQ System Cooking Grate, Summit series	7585
510	Weber Original Ebelskiver Bamboo Turners - discontinued	7589
510	Weber Original Gourmet BBQ System Sear Grate	8834
510	Weber Original Gourmet BBQ System Pizza Stone	8836